





































# Aurora Design Optional Pushbutton Quick Start Guide





















## Radio Pushbutton Actions




- |  |   |
|--|---|
|   Status Voice Assist    |    Sub-channel |
|   Virtual Fader          |   Virtual Balance   |
|   Auto Scan Start/Cancel |   Auto Scan Stop  |
|   Loudness/EQ*           |   AVC Toggle*   |
|   Next EQ/AVC*           |   Previous EQ/AVC*  |

## Bluetooth/USB Pushbutton Actions

- |   |   |
|---|---|
|   Pair/Voice Command<br>Conference Call |   Pause/Play Music<br>Mute/Unmute Call    |
|   Next Song<br>Accept Call              |   Previous Song<br>Reject/End Call        |
|   Next Album<br>(USB Sequential Only)   |   Previous Album<br>(USB Sequential Only) |
|   Bluetooth Reset ***                   |   |

## DAB/DAB+ Setup Pushbutton Actions\*\*

- |   |   |
|---|---|
|   DAB Setup /<br>DAB Edit     |   Status Voice Assist |
|   DAB Scan /<br>DAB Setup End |   Remove Station      |
|   Add Station                 |   Previous Station    |
|   Next Station                |   Previous Ensemble   |
|   Next Ensemble               |   |

 Quick press       Press 1 second       Press & hold

**Note:** All Pushbutton Actions can be used in place of or in tandem with the standard Control Actions.

\* See Advanced Features Guide. AVC pushbutton action only available when not in DAB radio mode. Next/Previous EQ/AVC only available when in radio mode and EQ or AVC Adjust modes. To enter Adjust mode, continue to hold pushbutton when turning EQ/AVC On until radio announces Adjust mode.

\*\* Radio must be in DAB/DAB+ operating mode. Once DAB Setup/Edit mode is entered, all other Pushbutton actions are overridden by DAB Pushbutton actions. See Advanced Features Guide (AVC pushbutton action only available when not in DAB radio mode). Any attached USB or connected Bluetooth devices will be disabled during DAB Setup. They will automatically return to normal operation when DAB Setup has ended.

\*\*\* Make sure no devices are connected. Immediately after turning radio on, press and hold button for 15 seconds. The Bluetooth module and custom name will be reset to factory settings. All pairings will be lost.

HD Radio™ Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. For patents see <http://dts.com/patents>. HD Radio, Artist Experience, and the HD, HD Radio, and "ARC" logos are registered trademarks or trademarks of iBiquity Digital Corporation in the United States and/or other countries.